

System	Date of Issue	Type of Service Information
Odyne Systems	12/03/19	<input type="checkbox"/> Troubleshooting <input checked="" type="checkbox"/> Procedure

Title: PTO Drag Brake Removal Procedure

Applies To: All Odyne Hybrid Systems.

Special tools or Software Required:

Tools or Supplies
N/A


The information in this Service Information is intended for use by trained, professional technicians with the knowledge, tools, and equipment to do the job properly and safely. It informs these technicians of conditions that may occur on some vehicles, or provides information that could assist in proper vehicle service. Warranty Policy documentation determines Warranty coverage unless stated otherwise. The information in this Service Information was current at the time of printing. Odyne Systems, LLC reserves the right to supersede this information with updates. The most recent information is available through Odyne on-line technical resources




Service Procedure:

Before Starting Procedure: Remove key from ignition and store in a safe place.

1. Locate the two Allen plugs on the end of the PTO opposite of the output shaft.



2. Remove the two Allen plugs, exposing the drag brake springs.



The information in this Service Information is intended for use by trained, professional technicians with the knowledge, tools, and equipment to do the job properly and safely. It informs these technicians of conditions that may occur on some vehicles, or provides information that could assist in proper vehicle service. Warranty Policy documentation determines Warranty coverage unless stated otherwise. The information in this Service Information was current at the time of printing. Odyne Systems, LLC reserves the right to supersede this information with updates. The most recent information is available through Odyne on-line technical resources

- Using a pick or screwdriver remove the drag brake springs from each hole and discard.



- Reinstall the Two Allen plugs.

Parts Required:

Part Number	Description	Quantity
NA	NA	NA

Odyne Service Support Resources:

To request technical assistance, contact ServiceSupport@Odyne.com.

To request parts, contact Parts@Odyne.com.

The information in this Service Information is intended for use by trained, professional technicians with the knowledge, tools, and equipment to do the job properly and safely. It informs these technicians of conditions that may occur on some vehicles, or provides information that could assist in proper vehicle service. Warranty Policy documentation determines Warranty coverage unless stated otherwise. The information in this Service Information was current at the time of printing. Odyne Systems, LLC reserves the right to supersede this information with updates. The most recent information is available through Odyne on-line technical resources